

SINEAX DME 400 with LONWORKS® Interface

Programmable multi-transducer

for the measurement of electrical variables in heavy-current power system

Application

SINEAX DME 400 (Fig. 1) is a programmable transducer with a LONWORKS® Interface that simultaneously measures several variables of a heavy-current power system.

The device conforms to the LONMARK® interoperability guidelines, Version 3.0. The measured variables are transferred by means of standard network variable types (SNVT) and are available at the LON interface.

The device is programmed using the LONTALK® file transfer protocol. The transducers are also equipped with an **RS 232** serial interface to which a PC with the corresponding software can be connected for programming or accessing and executing useful ancillary functions.

The usual methods of connection, the rated values of the input variables and the type of internal power metering are the main parameters that can be programmed.

The ancillary functions include a power system check, a facility for printing rating labels and provision for reading and setting the power meter.

The transducer fulfils all the essential requirements and regulations concerning electromagnetic compatibility (**EMC**) and **safety** (IEC 1010 resp. EN 61 010). It was developed and is manufactured and tested in strict accordance with the **quality assurance standard** ISO 9001.

Features / Benefits

- Transfer of data via a LON interface with an FTT-10A transceiver and LONTALK® protocol
- Simultaneous measurement of several variables of a heavy-current power system / full supervision of an asymmetrically loaded four-wire power system, rated current 1 to 6 A, rated voltage 57 to 400 (phase-to-neutral) or 100 to 693 V (phase-to-phase)

Measured variables	Output	Types
Current, voltage (rms), active/reactive/apparent power cosφ, sinφ, power factor	Data bus LON	DME 400
	2 analogue outputs and 4 digital outputs	DME 424
RMS value of the current with wire setting range (bimetal measuring function)	or 4 analogue outputs and	DME 442
Slave pointer function for the measurement of the RMS value IB	2 digital outputs see Data Sheet	
Frequency	DME 424/442-1 Le	
Average value of the currents with sign of the active power (power system only)	4 analogue outputs and bus RS 485 (MODBUS) see Data Sheet	DME 440
	DME 440-1 Le	

- For all heavy-current power systems variables



Fig. 1. SINEAX DME 400 in housing T24, clipped onto a top-hat rail.

- Input voltage up to 693 V (phase-to-phase)
- High accuracy: U/I/P 0.2% (under reference conditions)
- Up to 4 integrated power meters, storage every each 203 s, storage for: 20 years
- Windows software with password protection for programming, data analysis, power system status simulation, acquisition of meter data and making settings
- AC/DC power supply / universal
- Provision for either snapping the transducer onto top-hat rails or securing it with screws to a wall or panel




Fig. 2. Block diagram.

SINEAX DME 400 with LONWORKS® Interface

Programmable multi-transducer

Symbols

Symbols	Meaning	Symbols	Meaning
X	Measured variable	P3	Active power phase 3 (phase-to-neutral L3 – N)
X0	Lower limit of the measured variable	Q	Reactive power of the system $Q = Q1 + Q2 + Q3$
X1	Break point of the measured variable	Q1	Reactive power phase 1 (phase-to-neutral L1 – N)
X2	Upper limit of the measured variable	Q2	Reactive power phase 2 (phase-to-neutral L2 – N)
U	Input voltage	Q3	Reactive power phase 3 (phase-to-neutral L3 – N)
Ur	Rated value of the input voltage	S	Apparent power of the system $S = \sqrt{I_1^2 + I_2^2 + I_3^2} \cdot \sqrt{U_1^2 + U_2^2 + U_3^2}$
U 12	Phase-to-phase voltage L1 – L2	S1	Apparent power phase 1 (phase-to-neutral L1 – N)
U 23	Phase-to-phase voltage L2 – L3	S2	Apparent power phase 2 (phase-to-neutral L2 – N)
U 31	Phase-to-phase voltage L3 – L1	S3	Apparent power phase 3 (phase-to-neutral L3 – N)
U1N	Phase-to-neutral voltage L1 – N	Sr	Rated value of the apparent power of the system
U2N	Phase-to-neutral voltage L2 – N	PF	Active power factor $\cos\varphi = P/S$
U3N	Phase-to-neutral voltage L3 – N	PF1	Active power factor phase 1 P1/S1
UM	Average value of the voltages (U1N + U2N + U3N) / 3	PF2	Active power factor phase 2 P2/S2
I	Input current	PF3	Active power factor phase 3 P3/S3
I1	AC current L1	QF	Reactive power factor $\sin\varphi = Q/S$
I2	AC current L2	QF1	Reactive power factor phase 1 Q1/S1
I3	AC current L3	QF2	Reactive power factor phase 2 Q2/S2
Ir	Rated value of the input current	QF3	Reactive power factor phase 3 Q3/S3
IM	Average value of the currents (I1 + I2 + I3) / 3	LF	Power factor of the system $LF = \text{sgn}Q \cdot (1 - PF)$
IMS	Average value of the currents and sign of the active power (P)	LF1	Power factor phase 1 $\text{sgn}Q1 \cdot (1 - PF1)$
IB	RMS value of the current with wire setting range (bimetal measuring function)	LF2	Power factor phase 2 $\text{sgn}Q2 \cdot (1 - PF2)$
BS	Slave pointer function for the measurement of the RMS value IB	LF3	Power factor phase 3 $\text{sgn}Q3 \cdot (1 - PF3)$
φ	Phase-shift between current and voltage	H	Power supply
F	Frequency of the input variable	Hn	Rated value of the power supply
P	Active power of the system $P = P1 + P2 + P3$		
P1	Active power phase 1 (phase-to-neutral L1 – N)		
P2	Active power phase 2 (phase-to-neutral L2 – N)		

Applicable standards and regulations

DIN En 60 688	Electrical measuring transducers for converting AC electrical variables into analogue and digital signals
IEC 1010 or EN 61 010	Safety regulations for electrical measuring, control and laboratory equipment
EN 60529	Protection types by case (code IP)
IEC 255-4 Part E5	High-frequency interference test (solid-state relays only)
IEC 1000-4-2, 3, 4, 6	Electromagnetic compatibility for industrial-process measurement and control equipment
VDI/VDE 3540, page 2	Reliability of measuring and control equipment (classification of climates)
DIN 40 110	AC quantities
DIN 43 807	Terminal markings
IEC 68 /2-6	Basic environmental testing procedures, vibration, sinusoidal
EN 55011	Electromagnetic compatibility of data processing and telecommunication equipment Limits and measuring principles for radio interference and information equipment
IEC 1036	Solid state AC watt hour meters for active power (Classes 1 and 2)
DIN 43864	Current interface for the transmission of impulses between impulse encoder counter and tariff meter
UL 94	Tests for flammability of plastic materials for parts in devices and appliances
LONMARK®	Interoperability guidelines, Version 3.0

Technical data

Inputs

Input variables:	see Tables 3 and 4
Measuring ranges:	see Tables 3 and 4
Waveform:	Sinusoidal
Rated frequency:	50...60 Hz; 16 2/3 Hz
Consumption:	Voltage circuit: $\leq U^2 / 400 \text{ k}\Omega$ Condition: Characteristic XH01 ... XH10 Current circuit: $\leq 0.3 \text{ VA} \cdot I/5 \text{ A}$

Continuous thermal ratings of inputs


Current circuit	10 A 400 V single-phase AC system 693 V three-phase system
Voltage circuit	480 V single-phase AC system 831 V three-phase system

Short-time thermal rating of inputs

Input variable	Number of inputs	Duration of overload	Interval between two overloads
Current circuit	400 V single-phase AC system 693 V three-phase system		
100 A	5	3 s	5 min.
250 A	1	1 s	1 hour
Voltage circuit	1 A, 2 A, 5 A		
Single-phase AC system 600 V $H_{\text{intern}}: 1.5 \text{ Ur}$	10	10 s	10 s
Three-phase system 1040 V $H_{\text{intern}}: 1.5 \text{ Ur}$	10	10 s	10 s

LONWORKS® Interface

Standard program ID:	80 00 36 15 03 04 04 01
Network protocol:	LONTALK®
Transmission medium:	Echelon FTT-10A transceiver, transformer coupled, reverse polarity protected, twisted 2-wire cable
Transmission speed:	78 kBit/s
Node within a subnet:	127
Subnet:	255
Number of nodes per network:	Max. 32'385
Bus termination:	External
Terminals:	Screw terminals, terminals 15 and 16



LONWORKS®, LONTALK® and NEURON® are registered trademarks of the Echelon Corporation.

SINEAX DME 400 with LONWORKS® Interface

Programmable multi-transducer

Table 1: Standard network variable types (according to application)

Symbols	Meaning	Application (see Table 4)		
		A11 ... A16	A34	A24 / A44
U	Input voltage	●	—	—
U12	Phase-to-phase voltage L1 – L2	—	●	●
U23	Phase-to-phase voltage L2 – L3	—	●	●
U31	Phase-to-phase voltage L3 – L1	—	●	●
U1N	Phase-to-neutral voltage L1 – N	—	—	●
U2N	Phase-to-neutral voltage L2 – N	—	—	●
U3N	Phase-to-neutral voltage L3 – N	—	—	●
UM	Average value of the voltages	—	—	●
I	Input current	●	—	—
I1	AC current L1	—	●	●
I2	AC current L2	—	●	●
I3	AC current L3	—	●	●
IM	Average value of the currents	—	●	●
IMS	Average value of the currents and sign of the active power	—	●	●
IB	RMS value of the current with wire setting range (bimetal measuring function)	●	—	—
IB1	RMS value of the current with wire setting range (bimetal measuring function), phase 1	—	●	●
IB2	RMS value of the current with wire setting range (bimetal measuring function), phase 2	—	●	●
IB3	RMS value of the current with wire setting range (bimetal measuring function), phase 3	—	●	●
BS	Slave pointer function for the measurement of the RMS value IB	●	—	—
BS1	Slave pointer function for the measurement of the RMS value IB, phase 1	—	●	●
BS2	Slave pointer function for the measurement of the RMS value IB, phase 2	—	●	●
BS3	Slave pointer function for the measurement of the RMS value IB, phase 3	—	●	●
F	Frequency of the input variable	●	●	●
P	Active power of the system	●	●	●
P1	Active power phase 1 (phase-to-neutral L1 – N)	—	—	●

Continuation of Table 1:

Symbols	Meaning	Application (see Table 4)		
		A11 ... A16	A34	A24 / A44
P2	Active power phase 2 (phase-to-neutral L2 – N)	—	—	●
P3	Active power phase 3 (phase-to-neutral L3 – N)	—	—	●
PF	Active power factor $\cos\phi = P/S$	●	●	●
PF1	Active power factor phase 1, P1/S1	—	—	●
PF2	Active power factor phase 2, P2/S2	—	—	●
PF3	Active power factor phase 3, P3/S3	—	—	●
Q	Reactive power of the system	●	●	●
Q1	Reactive power phase 1 (phase-to-neutral L1 – N)	—	—	●
Q2	Reactive power phase 2 (phase-to-neutral L2 – N)	—	—	●
Q3	Reactive power phase 3 (phase-to-neutral L3 – N)	—	—	●
S	Apparent power of the system	●	●	●
S1	Apparent power phase 1 (phase-to-neutral L1 – N)	—	—	●
S2	Apparent power phase 2 (phase-to-neutral L2 – N)	—	—	●
S3	Apparent power phase 3 (phase-to-neutral L3 – N)	—	—	●
LF	Power factor of the system	●	●	●
LF1	Power factor phase 1	—	—	●
LF2	Power factor phase 2	—	—	●
LF3	Power factor phase 3	—	—	●
QF	Reactive power factor $\sin\phi = Q/S$	●	●	●
QF1	Reactive power factor phase 1, Q1/S1	—	—	●
QF2	Reactive power factor phase 2, Q2/S2	—	—	●
QF3	Reactive power factor phase 3, Q3/S3	—	—	●
EA	Power meter 1	●	●	●
EB	Power meter 2	●	●	●
EC	Power meter 3	●	●	●
ED	Power meter 4	●	●	●

Where c.t.'s and/or v.t.'s are used for measurement, the values are referred to the primaries of the transformers.

Variables

- Power meter reset
- Maximum value pointer reset

SINEAX DME 400 with LONWORKS® Interface

Programmable multi-transducer

Reference conditions

Ambient temperature:	+ 23 °C ± 1 K
Input variable:	Rated useful range
Power supply:	H = H _n ± 1%
Active/reactive factor:	cosφ = 1 resp. sinφ = 1
Frequency:	50 ... 60 Hz, 16 2/3 Hz
Waveform:	Sinusoidal, form factor 1.1107
Miscellaneous:	DIN EN 60 688

System response

Accuracy class:	0.2 resp. 0.4 at applications with phase-shift
Duration of the measurement cycle:	Depending on measured variable and programming
Response time:	1 ... 2 times the measurement cycle

Influencing quantities and permissible variations

Acc. to DIN IEC 688

Safety

Protection class:	II
Enclosure protection:	IP 40, housing IP 20, terminals
Overvoltage category:	III
Insulation test:	Input voltage: AC 400 V Input current: AC 400 V Output: DC 40 V Power supply: AC 400 V DC 230 V
Surge test:	5 kV; 1,2/50 μs; 0,5 Ws
Test voltages:	50 Hz, 1 min. according to DIN EN 61 010-1 5550 V, inputs versus all other circuits as well as outer surface 3250 V, input circuits versus each other 3700 V, power supply versus outputs and SCI as well as outer surface 490 V, outputs and SCI versus each other and versus outer surface

Power supply →○

AC voltage: 100, 110, 230, 400, 500 or 693 V, ± 10%, 45 to 65 Hz
Power consumption approx. 10 VA

AC/DC power pack (DC and 50 ... 60 Hz)


Table 2: Rated voltages and tolerances

Rated voltage U _N	Tolerance
24 ... 60 V DC/AC	DC – 15 ... + 33%
85 ... 230 V DC/AC	AC ± 10%

Consumption: ≤ 9 W resp. ≤ 10 VA

Programming connector on transducer

Interface: RS 232 C
DSUB socket: 9-pin



The interface is electrically insulated from all other circuits.

Installation data

Housing: Housing **T24**
See Section "Dimensioned drawings"

Housing material: Lexan 940 (polycarbonate), flammability class V-0 acc. to UL 94, self-extinguishing, non-dripping, free of halogen

Mounting: For snapping onto top-hat rail (35 × 15 mm or 35 × 7.5 mm) acc. to EN 50 022
or
directly onto a wall or panel using the pull-out screw hole brackets

Orientation: Any

Weight: With supply transformer approx. 1.1 kg
With AC/DC power pack approx. 0.7 kg

Terminals

Type: Screw terminals with wire guards
Max. wire gauge: ≤ 4.0 mm² single wire or 2 × 2,5 mm² fine wire

Vibration withstand

(tested according to DIN EN 60 068-2-6)

Acceleration: ± 2 g
Frequency range: 10 ... 150 ... 10 Hz, rate of frequency sweep: 1 octave/minute
Number of cycles: 10 in each of the three axes

Result:	No faults occurred, no loss of accuracy and no problems with the snap fastener	Variations due to ambient temperature:	$\pm 0.1\% / 10\text{ K}$
Ambient conditions		Nominal range of use for temperature:	0...15...30...45 °C (usage group II)
Climatic rating:	Climate class 3 acc. to VDI/VDE 3540	Storage temperature:	-40 to +85 °C
		Annual mean relative humidity:	$\leq 75\%$

Basic programming

A version of the SINEAX DME 400 transducer with a **basic** program is also available which is recommended if the programming data are unknown at the time of ordering (see "Table 3: Ordering information", Feature 6).

Basic programming	Marking
Application:	4-wire, 3-phase system, asymmetric load (NPS)
Input voltage:	Design value $U_r = 100\text{ V}$
Input current:	Design value $I_r = 2\text{ A}$ without specification of primary rating
Power meter 1:	P System (incoming)
Power meter 2:	Q System (inductive)
Power meter 3:	P1 L1 (incoming)
Power meter 4:	I1 L1
	A 44
	U 21
	V 2
	W 0
	EA 58
	FA 62
	GA 59
	HA 51

Table 3: Ordering information

DESCRIPTION	MARKING
1. Mechanical design Housing T24 for rail and wall mounting	400 - 1
2. Rated frequency	
1) 50 Hz (60 Hz possible without additional error; 16 2/3 Hz, additional error $1.25 \cdot c$)	1
2) 60 Hz (50 Hz possible without additional error; 16 2/3 Hz, additional error $1.25 \cdot c$)	2
3) 16 2/3 Hz (not re-programming by user, 50/60 Hz possible, but with additional error $1.25 \cdot c$)	3
3. Power supply	
Nominal range	
1) AC 90 ... 110 V $H_n = 100\text{ V}$	1
2) AC 99 ... 121 V $H_n = 110\text{ V}$	2
3) AC 207 ... 253 V $H_n = 230\text{ V}$	3
4) AC 360 ... 440 V $H_n = 400\text{ V}$	4
5) AC 450 ... 550 V $H_n = 500\text{ V}$	5
6) AC 623 ... 762 V $H_n = 693\text{ V}$	6
7) DC/AC 20 ... 80 V DC / 22 ... 66 V AC 24 ... 60 V	7
8) DC/AC 72 ... 306 V DC / 76 ... 253 V AC 85 ... 230 V	8
4. Power supply connection	
1) External (standard)	1
2) Internal from voltage input	2
Line 2: Not available for rated frequency 16 2/3 Hz and applications A15 / A16 / A24 Caution: The power supply voltage must agree with the input voltage (Table 4)!	

Table 3 continued on next page!

SINEAX DME 400 with LONWORKS® Interface

Programmable multi-transducer

Continuation "Table 3: Ordering information"

DESCRIPTION	MARKING
5. Test certificate	
0) None supplied	0
1) Supplied	1
6. Programming	
0) Basic	0
9) According to specification	9
Line 0: Not available if the power supply is taken from the voltage input	
Line 9: All the programming data must be entered on Form W 2388 e and the form must be included with the order, if the primary values of the measured variables or meter readings have to be transferred.	

Table 4: Programming

DESCRIPTION	Application		
	A11 ... A16	A34	A24 / A44
1. Application (system)			
Single-phase AC	A11	—	—
3-wire, 3-phase symmetric load, phase-shift U: L1-L2, I: L1*	A12	—	—
3-wire, 3-phase symmetric load	A13	—	—
4-wire, 3-phase symmetric load	A14	—	—
3-wire, 3-phase symmetric load, phase-shift U: L3-L1, I: L1*	A15	—	—
3-wire, 3-phase symmetric load, phase-shift U: L2-L3, I: L1*	A16	—	—
3-wire, 3-phase asymmetric load	—	A34	—
4-wire, 3-phase asymmetric load	—	—	A44
4-wire, 3-phase asymmetric load, open Y	—	—	A24
2. Input voltage			
Rated value $U_r = 57.7 \text{ V}$	U01	—	—
Rated value $U_r = 63.5 \text{ V}$	U02	—	—
Rated value $U_r = 100 \text{ V}$	U03	—	—
Rated value $U_r = 110 \text{ V}$	U04	—	—
Rated value $U_r = 120 \text{ V}$	U05	—	—
Rated value $U_r = 230 \text{ V}$	U06	—	—
Rated value U_r [M]	U91	—	—
Rated value $U_r = 100 \text{ V}$	U21	U21	U21
Rated value $U_r = 110 \text{ V}$	U22	U22	U22
Rated value $U_r = 115 \text{ V}$	U23	U23	U23
Rated value $U_r = 120 \text{ V}$	U24	U24	U24
Rated value $U_r = 400 \text{ V}$	U25	U25	U25
Rated value $U_r = 500 \text{ V}$	U26	U26	U26
Rated value U_r [M]	U93	U93	U93
Lines U01 to U06 and U91: Only for single phase AC current or 4-wire, 3-phase symmetric load			
Line U91: U_r [M] 57 to 400			
Line U93: U_r [M] > 100 to 693			

* Accuracy class 0.4

Table 4 continued on next page!

Continuation "Table 4: Programming"

DESCRIPTION	A11 ... A16	Application A34	A24 / A44
3. Input current			
Rated value $I_r = 1 \text{ A}$ V1	V1	V1	
Rated value $I_r = 2 \text{ A}$ V2	V2	V2	
Rated value $I_r = 5 \text{ A}$ V3	V3	V3	
Rated value $I_r > 1 \text{ to } 6$ [A]	V9	V9	V9
4. Primary rating (primary transformer)			
Without specification of primary rating	W0	W0	W0
CT = [] A / I_r A VT = [] kV / U_r V	W9	W9	W9
Line W9: Specify transformer ratio prim. 1000 A; 33 kV			
5. Power meter 1			
Not used	EA00	EA00	EA00
I System [Wh]	EA50	—	—
I1 L1 [Wh]	—	EA51	EA51
I2 L2 [Wh]	—	EA52	EA52
I3 L3 [Wh]	—	EA53	EA53
S System [Wh]	EA54	EA54	EA54
S1 L1 [Wh]	—	—	EA55
S2 L2 [Wh]	—	—	EA56
S3 L3 [Wh]	—	—	EA57
P System (incoming) [Wh]	EA58	EA58	EA58
P1 L1 (incoming) [Wh]	—	—	EA59
P2 L2 (incoming) [Wh]	—	—	EA60
P3 L3 (incoming) [Wh]	—	—	EA61
Q System (inductive) [Wh]	EA62	EA62	EA62
Q1 L1 (inductive) [Wh]	—	—	EA63
Q2 L2 (inductive) [Wh]	—	—	EA64
Q3 L3 (inductive) [Wh]	—	—	EA65
P System (outgoing) [Wh]	EA66	EA66	EA66
P1 L1 (outgoing) [Wh]	—	—	EA67
P2 L2 (outgoing) [Wh]	—	—	EA68
P3 L3 (outgoing) [Wh]	—	—	EA69
Q System (capacitive) [Wh]	EA70	EA70	EA70
Q1 L1 (capacitive) [Wh]	—	—	EA71
Q2 L2 (capacitive) [Wh]	—	—	EA72
Q3 L3 (capacitive) [Wh]	—	—	EA73
6. Power meter 2			
Same as power meter 1, but markings start with a capital F	FA ..	FA ..	FA ..
7. Power meter 3			
Same as power meter 1, but markings start with a capital G	GA ..	GA ..	GA ..
8. Power meter 4			
Same as power meter 1, but markings start with a capital H	HA ..	HA ..	HA ..


Note: The meter reading is referred to the power $P = I \cdot U_p$ for I, respectively $I1 \cdot U_p$ for I1, $I2 \cdot U_p$ for I2 and $I3 \cdot U_p$ for I3 where U_p = the primary rated voltage or the secondary rated voltage if there is no v.t..

SINEAX DME 400 with LONWORKS® Interface

Programmable multi-transducer

Electrical connections


Function		Connection			
Meas. input ⊖→	AC current	IL1	1 / 3		
		IL2	4 / 6		
		IL3	7 / 9		
	AC voltage	UL1	2		
		UL2	5		
		UL3	8		
	N	11			
Outputs ⊖→	Analogue	A	+	15	
			-	16	
		B	+	17	
			-	18	
		C	⊖→ E	+	19
			⊖→ F	+	21
	Digital	G	+	23	
			-	24	
		H	+	25	
			-	26	
		Power supply AC →⊖	~	~	13
				~	14
DC	+		13		
	-		14		



If power supply is taken from the measured voltage internal connections are as follow::

Application (system)	Internal connection Terminal / System
Single phase AC current	2 / 11 (L1 - N)
4-wire 3-phase symmetric load	2 / 11 (L1 - N)
All other (apart from A15 / A16 / A24)	2 / 5 (L1 - L2)

Measuring input




Measuring input

System / application

Terminals


**3-wire
3-phase
symmetric
load
I: L1**



Connect the voltage according to the following table for current measurement in L2 or L3:

Current transformer	Terminals	2	5	8
L2	1 3	L2	L3	L1
L3	1 3	L3	L1	L2


**3-wire
3-phase
symmetric
load
Phase-shift
U: L1 – L2
I: L1**



Connect the voltage according to the following table for current measurement in L2 or L3:

Current transformer	Terminals	2	5
L2	1 3	L2	L3
L3	1 3	L3	L1

**3-wire
3-phase
symmetric
load
Phase-shift
U: L3 – L1
I: L1**



Connect the voltage according to the following table for current measurement in L2 or L3:

Current transformer	Terminals	8	2
L2	1 3	L1	L2
L3	1 3	L2	L3

SINEAX DME 400 with LONWORKS® Interface


Programmable multi-transducer

Measuring input

System / application

Terminals


3-wire
3-phase
symmetric load
Phase-shift
U: L2 - L3
I: L1



Connect the voltage according to the following table for current measurement in L2 or L3:

Current transformer	Terminals			
	5	8	L2	L3
L2	1	3	L3	L1
L3	1	3	L1	L2


4-wire
3-phase
symmetric load
I: L1



Connect the voltage according to the following table for current measurement in L2 or L3:

Current transformer	Terminals			
	2	11	L2	L3
L2	1	3	L2	N
L3	1	3	L3	N

3-wire
3-phase
asymmetric load



Measuring inputs	
System / application	Terminals
4-wire 3-phase asymmetric load	
	<p>3 single-pole insulated voltage transformers in high-voltage system</p>
4-wire 3-phase asymmetric load, Open Y connection	<p>Low-voltage system</p>
	<p>2 single-pole insulated voltage transformers in high-voltage system</p>

Relationship between PF, QF and LF




Fig. 3. Active power PF —, reactive power QF -----, power factor LF -.-.-.

SINEAX DME 400 with LONWORKS® Interface

Programmable multi-transducer

Dimensioned drawings




Fig. 4. SINEAX DME 400 in housing **T24** clipped onto a top-hat rail (35 × 15 mm or 35 × 7.5 mm, acc. to EN 50 022).

Table 5: Accessories

Description	Order No.
Programming cable	980 179
PC software DME 4 (in German, English and French on two 3 1/2" discs)	131 144
Operating Instructions DME 400-1 Bd-f-e	127 119




Fig. 5. SINEAX DME 400 in housing **T24**, screw hole mounting brackets pulled out.



SINEAX DME 400 with LONWORKS® Interface

Programmable multi-transducer

Printed in Switzerland • Subject to change without notice • Edition 08.99 • Data sheet No. DME 400-1 Le

Camille Bauer Ltd

Aargauerstrasse 7
CH-5610 Wohlen/Switzerland
Phone +41 56 618 21 11
Fax +41 56 618 24 58
Telex 827 901 cbm ch

**GOSSEN
METRAWATT
CAMILLE BAUER**

